Q7C3 TROUBLE SHOOTING GUIDE

No Display or display is unstable:

1.1 Interface Board:



2. BUTTON function:

2.1 Control Board



3. OSD function:



4. Power Board