




FILE No.

PARTS LIST

Microwave Oven

EM-D975



SPECIFICATIONS

Power source : Local Voltage / Frequency

Power consumption : 900W

Dimension : 525(W) × 305(H) × 455(D)mm

Net Weight : Approx. 22kg.


Specifications subject to change without notice

Product Code	Model	Suffix	V/Hz/Plug	Color	Function	Cavity Volume	Control Panel	Destination
1 437 574 61	EM-D975	AP	240/50/O3	Silver	Touch	30 Liter, 1.1 Cu.ft	English	Australia


REFERENCE NO. PL-151007

CIRCUIT DIAGRAW

**NOTE: Door is closed
Unit is not operated**



EXPLODED VIEW



PARTS LIST

REF. NO.	PARTS NO.	DESCRIPTION	Q'TY
1	GA-SP04/P01-005	Door Frame	1
2	GA-SP04/P02-002	H.V. Fuse Holder	1
3	GA-SP04/P03-002	H.V. Capacitor Holder	1
4	GA-SP04/P04-002	Fan Shroud	1
5	GA-SP04/P05-002	Fan Blade	1
6	GA-SP04/P06-002	Door	1
7	GA-SP04/P07-002	Choke Cover	1
8	GA-SP04/P08-001	Washer	1
9	GA-SP04/P09-001	Turntable Connector	1
10	GA-SP04/P10-001	Roller Ring Ass'y	1
11	GA-SP04/P11-002	Turntable Glass Tray	1
12	GA-SP04/P13-002	Upper Hinge	1
13	GA-SP04/P15-003	Oven Cavity	1
14	GA-SP04/P16-005	Rating Label	1
15	GA-SP04/P17-005	Outer Cabinet	1
16	GA-SP04/P18-002	Back Stopper	1
17	GA-SP04/P19-001	Cord Stopper	1
18	GA-SP04/P20-002	Lamp Holder	1
19	GA-SP04/P21-002	Air Duct	1
20	GA-SP04/P22-004	Switch Holder	1
21	GA-SP04/P25-003	Oven Foot	4
22	GA-SP04/P26-003	Base Plate	1
23	GA-SP04/P27-003	Lower Hinge	1
24	GA-SP04/P28-005	Control Panel	1
25	GA-SP04/P29-005	Door Window	1
26	GA-SP04/P32-002	Push Button(Knob)	1
27	GA-SP04/P33-002	Control Knob	1
28	GA-SP04/P42-001	Display(window)	1
29	GA-SP04/P43-001	Outer Heat Insulated	1
30	GA-SP04/P45-001	Rear Outer Enclosure	1
31	GA-SP04/P46-001	Splash Shield	1
32	GA-SP04/P50-001	Heater Bracket	4
33	GA-SP04/P51-001	Inner Heat Insulated	1
34	GA-SP04/P52-001	Convectional Fan Sponge	1
35	GA-SP04/P54-001	Wire Fastener	2
36	GA-SP04/P55-001	Driving Belt	1
37	GA-SP04/P56-001	Bearing	1
38	GA-SP04/P57-001	Driving Wheel	1
39	GA-SP04/P58-001	Bracket(upper)	1
40	GA-SP04/P59-001	Rotational axis	1
41	GA-SP04/P60-001	bracket (lower)	1
42	GA-SP04/P61-001	Washer	1
43	GA-SP04/P62-001	Convectional fan blade	1
44	GA-SP04/P63-001	Thermostat bracket	2
45	GA-SP04/P64-001	Lamp bracket	1
46	GA-SP04/P65-001	Noise filter bracket	1
47	GA-SP04/P66-001	Baking Plate	1
48	GA-SP04/P67-001	Driving Fan blade	1
49	GA-SP04/P68-001	Motor Bracket	1
50	GA-SP04/P69-001	Heat Insulated	1
51	GA-SP04/P70-001	Right Heat Insulated Fibre Glass(rear)	1
52	GA-SP04/P71-001	Right Heat Insulated Fibre Glass(front)	1
53	GA-SP04/P72-001	Right Heat Insulated Fibre Glass(front)	1
54	GA-SP04/P73-001	Right Heat Insulated Fibre Glass(rear)	1
55	GA-SP04/P75-001	Spring	1
56	GA-SP04/P76-001	lower heater holder	1
57	GA-SP04/P77-001	upper heater holder	1
58	GA-SP04/P78-001	nut of heater	1
59	GA-SP04/P79-001	heater holder	1
60	GA-SP04/P80-001	Knob lid(upside)	1
61	GA-SP04/P81-001	Knob lid(lower)	1
62	GA-SP04/P82-001	wire holder(ceramic)	1
63	GA-SP04/C01-002	H.V.Fuse	1
64	GA-SP04/C02-002	H.V. Diode	1
65	GA-SP04/C03-004	H.V.Capacitor	1

PARTS LIST

66	GA-SP04/C04-003	Noise Filter	1
67	GA-SP04/C05-002	Fan motor	1
68	GA-SP04/C06-001	Oven Lamp	1
68	GA-SP04/C07-001	Oven Lamp	1
69	GA-SP04/C08-001	Magnetron	1
70	GA-SP04/C09-001	Primary Micro Switch	1
71	GA-SP04/C10-001	Monitor Micro Switch	1
72	GA-SP04/C11-001	Second Micro Switch	1
73	GA-SP04/C12-004	Transformer	1
74	GA-SP04/C13-002	Wire Harness	1
75	GA-SP04/C14-001	Power Cord&Plug	1
76	GA-SP04/C15-001	Turntable motor	1
77	GA-SP04/C17-004	PCB control	1
78	GA-SP04/C19-002	Thermostat	1
79	GA-SP04/C23-001	Heater	1
80	GA-SP04/C24-001	Sensor	1
81	GA-SP04/C25-001	Fan Motor(convection)	1
82	GA-SP04/C26-001	Heater of Grill	1
	GA-SP04/B04-005	Instruction Manual	1

Dec. / '04

SANYO

SANYO Electric Co., Ltd.
Osaka, Japan